

# Manufacturers of Quality Wood Mouldings

P.O. Box 488 310 Harrison Street Phone (870) 898-5146 Ashdown, Arkansas 71822 Little River Millwork has manufactured and distributed quality wood mouldings for over 30 years serving Arkansas, Louisiana and the surrounding area. We take pride in the quality of our products and in our service to all of our customers. We offer stain grade, finger-joint, primed finger-joint, MDF mouldings, and accessories. We maintain a large inventory of finished moulding, blanks, and raw material to have the moulding you need, when you need it. Our plant is located in Ashdown, Arkansas, assuring you that if we do sell out of a pattern, we will have it in a few days rather than in a few weeks as with foreign manufacturers.

White Fir's light color, long grain, and wood stability offer your customer a great choice in quality stain grade mouldings. We mill our solid White Fir stain grade mouldings at our Ashdown, Arkansas plant. We grade to high standards to offer you the best quality and inventory—over 150 different profiles to offer your customer a great choice.

Paint grade mouldings are offered both raw and pre-primed. Finger-joint mouldings—available in both pine and White Fir—offer your customer an economical option in paint grade wood mouldings. Pre-primed paint grade wood mouldings offer your customer a time-saving convenience. Using only quality latex primers, we prime our mouldings with a true prime coat, not a whitewash, and we bake on the finish.


Wood mouldings are shipped in random lengths from 6 ft. to 16 ft. in multiples of 1 ft. No more than 15% of any one pattern shall be under 8 ft. When computing the percentage of shorts in casing and stop, pieces 7 ft. in length are considered long lengths. There is an upcharge for specified lengths.


MDF mouldings offer a full-length, blemish-free moulding. We distribute various profiles from Pacific MDF Products, Inc. (Pac-Trim). Pac-Trim offers the best MDF product and finish available, using only domestic, moulding and better grade MDF for a strong, smooth finish. Pac-Trim primes with two coats of primer, buffing before and after each coat, for a smooth, ready-to-paint finish. We offer all of our patterns in the Pac-Lite, 38 lb. style, as it is the easiest for the installer to work with. Pac-Trim offers a selection of primed rosettes, plinth blocks, base corners, and crown corners to match and compliment their mouldings


Flexible mouldings allow the builder and designer flexibility not available in wood mouldings. We are a distributor of Carter Millwork's flexible mouldings in patterns that match our profiles. CarterFlex ships in-stock items the next day and most specials within one week. Circle top, arch top, elliptical and radius are formed pre-bent to match your application for ease of installation. CarterFlex mouldings machine like wood, can be painted or stained, and are acceptable for interior and exterior installations. CarterFlex carries a lifetime manufacturer's warranty.


Your order will arrive clean and dry in our fleet of modern trucks. Our trailers' flexible tops protect your order, and fold out of the way to make unloading easy. The whole top folds out of the way, allowing your forklift full access to your order.


We look forward to the opportunity to serve you for your moulding needs. We at Little River Millwork, Inc. take pride in our quality products, large selection, and fast, friendly service. Please call us with any questions or comments.













#### **CORNER GUARDS**

Outside Corner Guard is used to protect corners or to cover ragged edges where wall covering and painted surfaces meet at outside corners.









Used in concrete forms, making chamfered edge at concrete corners. Also used for coved problems of uneven joints where butted corners under laminate kitchen tops and under flooring.



panels, wallpaper, painted or contrasting surfaces meet. Gives corners a decorative, finished look.


### **GLASS** BEAD

**LRM 148** 3/8 x 3/8 WF




Joins two walls at an inside corner. Solves Used to hold glass in place. Also called Glass Stop, Cove & Bead, Putty Bead, Glazing Bead and Staff Bead.


#### **QUARTER ROUNDS**



**LRM 103** 1-1/16 x 1-1/16 WF,FJ



**LRM 106** 11/16 x 11/16 WF,FJ,PM, OAK



May be used as a Base Shoe,

Inside Corner Moulding, or to cover any 90 degree juncture.

**LRM 108** 1/2 x 1/2 WF



**LRM 110** 1/4 x 1/4 WF

#### **BASE SHOE**

Applied where Base Moulding meets floor. Protects Base from damage. Conceals uneven lines or cracks where Base meets floor.



1/2 x 3/4 7/16 x 3/4 WF, FJ, PM OAK



7/16 x 11/16 WF, FJ, PM




**LRM L129** 3/8 x 5/8 WF7'

WF

### SHELF EDGE SCREEN MOULD

Covers seam where screening is fastened to the screen frame Also covers particle or flake board shelf edges.




**LRM 137** 3/8 X 3/4 WF

**LRM 144** 1/4 X 3/4 WF

#### HALF ROUNDS

May be used as a Screen Moulding, Shelf Edging, Panel Mould



WF


DRIP CAPS

1/4 X 3/4


WF

Applied over exterior window & door frames. Keeps water from seeping under the siding. Directs water away from window glass.

WF



**LRM 188** 1-1/16 x 1-5/8



**LRM 197** 11/16 x 1-5/8

#### ROUNDS

Most often used as closet pole or room dividers.

LRM 233 1-1/4 x 1-1/4 WF

#### **PARTING STOP**



**LRM 254** 1/2 X 3/4 WF

#### **SQUARES**




**LRM 239** 11/16 X 11/16 WF



Used in cabinets, framing for shelves or other utilitarian uses. Also used as balasters for supporting stair handrails

#### SCREEN/S4S



**LRM 248** 11/16 x 1 3/4 WF, FJ, WFE4E

> **LRM 249** 11/16 x 1 5/8 WF, FJ

WF, FJ LRM 2500 11/16 x 1 1/2 WF, FJ, PM LRM 251 11/16 x 1 3/8 WF, FJ


Used in cabinets, framing for shelves or other utilitarian uses. Also used as balasters for supporting stair handrails.

#### LATTICE


LRM 265 1/4 x 1-3/4 WF LRM 266 1/4 x 1-5/8 WF LRM 267 1/4 x 1-3/8 WF LRM 268 1/4 x 1-1/8 WF

Originally used in trellis work. This small plain S4S Moulding is among the most versatile of profiles.

#### BASE CAP




**LRM THUMBNAIL** 11/16 x 1-1/2



**LRM 163** 11/16 x 1-3/8 WF



**LRM 164** 11/16 x 1-1/8 WF, FJ



A Decorative Accent installed flush against the wall on top of

a S4S Baseboard. Also used as a panel mould and an accent


**LRM 166** 11/16 x 1-1/4 WF

A rabbeted moulding used to surround the outside edge of




**LRM 172** 5/8 x 3/4 WF,FJ


#### **BACK BAND**



**LRM 238** 1-1/16 x 1-5/8 FJ



**LRM 125** 1 x 1-1/4 WF, FJ



**LRM 279** 1-1/16 x 1-1/8 WF, FJ




**LRM 280** 11/16 x 1-1/16 WF



**LRM 281** 11/16 x 1-1/8 WF


#### PANEL STRIPS/MULLION CASINGS



LRM 970 3/8 x 2-1/4 WF








LRM 975 3/8 x 2-1/4 SPL



LRM 978 3/8 x 1-3/4 WF

Mullion Casing, used to cover the joint between two window units. Panel Strip, used in decorative wall treatments.




LRM 980 3/8 x 2-1/4 SPL

LRM 982 3/8 x 2 SPL

LRM 983 3/8 x 1-3/4 WF

### HAND RAIL

Used as a hand support in a stairwell



**LRM 231** 1-1/2 x 1-11/16 WF



WF

**LRM 240** 1-1/4 x 1-1/4 WF

#### **NOSINGS**



**LRM NOSING 1-3/8** 7/16 x 1-3/8 WF



11/16 x 1-1/4 WF



LRM NOSING 1-5/8 11/16 x 1-5/8 F I



**LRM NOSING 2-1/4** 1-1/16 x 2-1/4

#### **FLAT STOOL**




A moulded edged trim used to finish the bottom of a window opening frame.

**LRM 1021** 11/16 x 5-1/4 WF, FJ, PM, MDF **LRM L1021** 11/16 x 5-3/4 FJ

#### RABBETED STOOL



LRM 1193 11/16 x 3-1/4 WF, FJ LRM 1194 11/16 x 2-3/4 WF LRM 1195 11/16 x 2-1/2 LRM 1196 11/16 x 2-1/4



LRM 1161 1-1/16 x 3-5/8 LRM 1163 1-1/16 x 3-1/4 WF LRM 1164 1-1/16 x 2-3/4

#### JAMBLINER/S4S

Used to line the inside of windows and can be used as a moulding and to build up stacked moulding.



 LRM JAMB LINER
 11/16 x 3-11/16 FJ

 LRM S4S-4
 11/16 x 3-1/4 WF, FJ

 LRM S4S-6
 11/16 x 5-1/4 WF, FJ

 LRM 1X4
 11/16 x 3-1/2 MDF

 LRM 1X6
 11/16 x 5-1/2 MDF

 LRM 1X8
 11/16 x 7-1/4 MDF

 LRM 1X12
 11/16 x 11-1/4 MDF

#### **BEAM BEAD**

An accent mould for the corners of beams and columns.


LRM BEAM BEAD 3/4 x 3/4 WF



#### CHAIR RAIL **PICTURE** MOULDING Used to support hooks for picture hanging. Applied around the room's circumference, near the ceiling line. **LRM 273** 11/16 x 1-3/4 WF, FJ A symmetrical pattern **BATTEN** used to conceal the line LRM 297 where two parallel boards LRM 298 **LRM 298R** 11/16 x 3 or panels meet. **LRM 390** 7/8 x 2 1/2 11/16 x 2 1/2 WF, FJ 11/16 x 2 5/8 WF WF WF, FJ, PM, MDF **LRM 229 LRM L224 LRM 224** 11/16 x 1-5/8 9/16 x 1 1/2 9/16 x 2-1/4 WF WF WF **FLAT ASTRAGALS** LRM LBD1 1 1/4 x 2 3/4 FJ **LRM 304H** 9/16 x 4 1/4 WF, FJ **LRM 300** 1 1/16 x 3 **LRM 133 LRM 134 LRM 135 LRM L 304H** 11/16 X 1-3/4 7/16 x 3/4 11/16 x 1-3/8 WF, FJ 21/32 X 6 WF WF WF FJ


Trims out the upper edge or top of a Wainscot. Covers plywood's rough Trims out the upper edge or top of a Wainscot. Covers plywood's rough sandwich edge in installations where it's exposed to view. Also called a Dado

WAINSCOT/PLY CAP Cap.




Originally used to trim out raised panel wall construction. Now, often used to frame attractive wall coverings for a paneled effect.

#### **PANEL MOULD**



## CASING



LRM ETRIM 5/8 x 2-1/2 WF, FJ, WF 7'

LRM 324 11/16 x 2-1/4 WF, FJ, PM WF7', FJ7', PM7'


**LRM PT 324** 9/16 x 2-1/4 MDF

LRM SL-6 5/8 x 2-1/8 WF,FJ,WF7'

LRM 329 11/16 x 2-1/4 WF, FJ, PM, WF7'

**LRM BABY HOWE** 11/16 x 2-1/4

**LRM ACASING** 5/8 x 2-1/2 WF, FJ, WF 7', FJ 7'



11/16 x 3 1/2 MDF

11/16 x 3 1/2


15/16 x 3 1/4

3/4 x 3-1/4 WF, FJ


13/16 x 3 WF, FJ, FJ 7'3"

9/16 x 3 1/4 FJ


## CASING




**LRM L356** 11/16 x 2-3/4 WF, FJ




**LRM 356** 11/16 x 2-1/4 WF, FJ, PM, MDF WF7', FJ7', PM7'




**LRM 366** 11/16 x 2-1/4 WF, FJ




**LRM 376** 11/16 x 2-1/4 FJ




**LRM 387** 5/8 x 2-1/4 WF




**LRM HI LINE** 5/8 x 2-1/4 WF, FJ




**LRM JB1** 1 1/4" x 2 1/4 FJ




**LRM SF-1** 11/16" x 2-1/2 FJ



LRM FOGELMAN 1-3/8" x 3 FJ




**LRM 140** 11/16 x 3 1/4 MDF



**LRM HI LINE**5/8 x 3-1/4
WF, FJ, PM
FJ 7'3"

## CASING



## CASINGS & BASES LRM 795 11/16 x 2-1/4 **LRM 444EE** WF 11/16 x 3-1/4 FJ LRM 444 LRM RM444 **LRM 445** LRM 683 5/8 x 3-1/4 11/16 x 3-1/4 11/16 x 3-1/4 11/16 x 3-1/4 WF, FJ, FJ 7'3" WF WF, FJ, PM, MDF WF, FJ, PM FJ 7'3"

LRM A BASE 9/16 x 3-1/8 WF, FJ LRM HILINE BASE 5/8 x 4-1/4 FJ

LRM L444

11/16 x 4-1/4

FJ

**CHARLESTON BASE** 

11/16 x 3-1/4

WF, FJ

LRM 723

7/16 x 3-1/4


WF, FJ

LRM 713


9/16 x 3-1/4

WF, FJ, PM

## **BASES**




**LRM 163 E-7** 11/16 X 7-1/4 MDF



## **DOOR TRIM**

**STOPS** 

In door trim, Stop is nailed to the faces of the door frame to prevent the door from swinging through. As window trim, stop holds the bottom sash of a double-hung window in place.




#### **BRICK MOULD**

**LRM 937** 

7/16 x 1-1/4 FJ

Used as an exterior door & window casing. A thick moulding providing a surface for brick or other siding to butt against.



**LRM 935** 

7/16 x 1-5/8 FJ

**LRM L933** 

7/16 x 2 WF

## JAMBS DOOR TRIM

# 11/16 x 4-9/16 WF, FJ

#### **INTERIOR FLAT JAMBS**



11/16 x 4-9/16 WF, WV, FJ, MDF 11/16 x 5-1/4 WF, WV, FJ 11/16 x 6-9/16 WF, WV, FJ

#### INTERIOR FLAT JAMBS

WITH TRIM GUIDES



11/16 x 4-9/16 FJ

#### **FRAMES**

**EXTERIOR FRAME**KERFED FOR WEATHERSTRIPPING





1-1/4 x 4-9/16 WF, FJ 1-1/4 x 5-1/4 WF, FJ 1-1/4 x 6-9/16 WF, FJ




1-1/4 x 4-9/16 WF, FJ 1-1/4 x 5-1/4 WF, FJ 1-1/4 x 6-9/16 WF, FJ

#### **T-ASTRAGALS**








#### MOULDING COMBINATIONS

Whether a large crown, a unique chair rail, or just a different look, combining moulding profiles in crease the possibilities. Combining standard profiles in different combinations can give you the depth and creativity. Combining casings and bases with crowns can create patterns that you could not find in a single profile. Tall, ornate bases, detailed casing, impressive chair rails, even fireplace mantels can have that special look.



When installing the different pieces of the combined profile, it is better to completely install the first piece for the whole progect, then add the second piece of the combination and then move on to the third piece, and so on. It is much easier to measure, cut and miter each piece as you come to it rather than construct the combined profile and then do the mitering. With such a large unit, there would be more margin for error.